



Kenwood KDC-BT362U Front Panel Replacement

This guide will demonstrate how to remove the front panel of the radio to access the internals of the device for repair.

Written By: Pablo Cabrera



INTRODUCTION

This guide is a prerequisite to getting inside your device for repair. Before any internal parts are replaced, the front panel must be completely removed. This removal allows for access into the device's interior.



TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Front Panel



- Locate the face-plate eject button.

Step 2



- Press the eject button with your forefinger.
- Remove the face-plate.

Step 3



- Starting on the top side, pop the front panel frame out.
- Remove the face-plate frame.

Step 4



- Use the plastic opening tool to pry open the tabs.
- Repeat on the opposite side.

Step 5



- Remove the front panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 04:32:53 PM.